

## MTS Release Notes

### MTS 4.4c:

- Skip to next not available when performing an N4th, Multistat or ZPlotLab step. Corrected.

### MTS 4.4a:

- Alarm settings in the .ini file have been changed. When updating software, it forces a change to the alarm settings. Using [Alarms] Lock=1 will block the forced alarm changes.
- If 500 SCCM is used with 500SCCM controller, the voltage is 5V, a rounding error can result is a value >5V casing an error message. Corrected.
- Ctrl+Alt+L will now display the Communications Log box.
- If an Alarm occurs during startup, alarm flow settings will be applied, but not displayed in the main window. Corrected.